

STEP 1

Download


Download the **Yoco Point of Sale app**



STEP 2

Login


Log into the Yoco app using the email and password you provided at signup.



STEP 3

Forgot Password


Use the forgot password link on the app or Business portal; portal.yoco.co.za to reset.



STEP 4

Tutorials

Select Menu > Tutorials for instructions on how to pair your card reader and do a test transaction.



STEP 5

Setup

Tell your customers that you accept card payments by setting up your Yoco table tent and sticker. Find these behind this user guide.

READY,
SET...
GROW!



Meet your Yoco Wireless Pro card reader!

- 1 Power button
- 2 Red light (charging)
- 3 Green tick
- 4 Bluetooth symbol
- 5 Bluetooth flashing light
- 6 Battery symbol
- 7 Chip and pin
- 8 Swipe and sign
- 9 Reset button
- 10 Charging port
- 11 Serial number



Need Help?

Visit our help centre for support articles and chat to our support team online.

support.yoco.co.za

support@yoco.co.za

9am - 10pm Daily

Share your Yoco experience or tell a friend about Yoco!



@Yoco_ZA /YocoZA @yoco_ZA

Tell a friend about Yoco! Find your Yoco promo code in your Yoco Point of Sale app or Yoco Business Portal and earn R500 for every friend you refer. T&Cs apply.

yoco.co.za



Wireless Pro
card reader

Quick Start Guide



For iOS and Android